

PILLOW BLOCK

Ball Bearing, Die-Cast Housing, Rigid Type PBDC-BL - Series	Page 4
Ball Bearing, Pressed Steel Housing, Self-Aligning, Standard Type PBPS-BL - Series	Page 4
Ball Bearing, Pressed Steel Housing, Self-Aligning, Heavy Gauge Type PBPH-BL - Series	Page 4
Bronze Bearing, Die-Cast Housing, Rigid Type PBDC-BR - Series	Page 4
Bronze Bearing, Pressed Steel Housing, Self-Aligning Type PBPS-BR - Series	Page 5
UHMW-PE Bearing, Solid-Rigid Type PBUH-UH - Series	Page 5
UHMW-PE Bearing, Pressed Stainless Steel Housing, Self-Aligning Type PBSS-UH - Series	Page 5
Replacement Parts	Page 5

FLANGE MOUNT

Ball Bearing, Die-Cast Housing, Rigid Type (2 Bolt) F2DC-BL - Series	Page 6
Ball Bearing, Pressed Steel Housing, Self-Aligning, Standard Type F2PS-BL Series	Page 6
Ball Bearing, Pressed Steel Housing, Self-Aligning, Heavy Gauge Type F2PH-BL - Series	Page 6
Bronze Bearing, Pressed Steel Housing, Self-Aligning Type F2PS-BR - Series	Page 6
UHMW-PE Bearing, Pressed Stainless Steel Housing, Self-Aligning Type F2SS-UH - Series	Page 6
Ball Bearing, Die-Cast Housing, Rigid Type (4 Bolt) F4DC-BL - Series	Page 7
UHMW-PE Bearing, Solid-Rigid Type (4 Bolt) F4UH-UH Series	Page 7
UHMW-PE Bearing, Solid-Rigid Type (2 Bolt) F2UH-UH - Series	Page 7

SLEEVE BEARINGS

Bronze Sleeve Bearings	Page 7
UHMW-PE Sleeve Bearings	Page 7

BEARING KIT – 9

This set installs or removes internal bushings & bearings with I.D. 1-5/16" to 1-3/4" and O.D. 1-7/16" to 1-7/8". Set contains 1 driver & 7 adapters.



BEARING KIT – 22

This set installs or removes internal bushings & bearings with I.D. 3/8" to 1-1/2" and O.D. 7/16" to 1-3/8". Set contains 3 drivers & 16 adapters.



BEARING KIT – 18

This set installs or removes internal bushings & bearings and will notpeen the bushing end, scratch or mar. Set contains 9 adapters for I.D. sizes 1/2" to 1" in increments of 1/16" maximum O.D. of 1-1/8".

